


PROGRAMMING THE KEY FOB

1. Turn the joystick on by pressing the  button
 - (a) The joystick should beep, and a solid blue light will appear on the joystick membrane
 - (b) If you have a bow thruster – Hold the *top* two buttons down simultaneously on the key fob until you hear a beep (around 5 seconds)
 - (c) If you have a stern thruster - Hold the *bottom* two buttons down simultaneously on the key fob until you hear a beep (around 5 seconds)

2. Test the thruster with the joystick and the key fob